07877743921
sales@x-mods.co.uk
www.x-mods.co.uk
xmodscontrollers
X_MODS_LTD

THE CARNAGE MOD USER GUIDE - 36 MODES

TURNING THE MOD ON AND OFF

The SYNC button serves as a convenient way to toggle the mod on and off effortlessly. A single tap of the SYNC button activates the mod, and the LED will flash three times to indicate its activation. After that, the LED will flash the mode number it is currently in, which is the same mode you were using when you last turned it off.
When you wish to turn the mod off, just tap the SYNC button once again. The LED will then flash four times, signaling that the mod is in the process of shutting down, and after the fourth flash, the mod will be completely turned off.

CHANGING MODES

To change modes hold LT and tap the SYNC button. Each time you hold LT and tap SYNC you start from mode 1, so if for example you were in mode 10 and wanted mode 11 you would have to tap sync 11 times. Once LT is released, the LED will flash the mode number (5 flashes for mode 5 etc). If the mode is over 10 (11-18) the LED will do one long flash to represent the 10 then flash the rest as normal.

ENTERING A "SUB MODE"

To switch between Main and Sub Modes; hold A and tap SYNC, the LED will flash twice slowly to show it is entering the Sub Modes or once to show its entering the Main Modes, it will then flash the Mode number. The mod will remember which mode you were in, for example you can be in Mode 6 then switch to Sub Mode 1.

RESETTING A MODE BACK TO DEFAULT SPEED (7 S.P.S)

To reset a Mode back to the default speed, first enter programming by holding the RT and pressing the SYNC button, then reset the Mode by holding the LT and tapping SYNC. The player LED will flash 3 quick flashes, then reflash the Mode number.

MODES EXPLAINED

Right Trigger Rapid Fire
Rapid fire turns semi automatic weapons into full automatics (max speeds set by the game, not the mod)

Mimic Akimbo
While pressing only RT both RT and LT will rapid fire.

Quick Scope
Quickly Press and release the left trigger (LT) and the player will scope and shoot at the perfect timing.

Quick Scope Sniper Breath
Same as above but the player will also take a breath.

Quick Scope Double Shot
Same as quick scope but the player fires 2 shots (3 with some rifles, doesnt work with bolt action weapons).

Autorun
Run without having to keep the left thumbstick pressed. We recommend using, marathon and ready up with the auto run modes.

Drop Shot
Hold (RT) to make your player go prone while shooting, once you start to go prone LT can be pressed to aim in.

Aim Kneel Reset
Aiming in with LT will drop the player to his knee, when LT is released the player will stand back up.

Auto ADS
Aim and shoot while only pressing the right trigger.

3 or 5 Round Burst/Rapid fire
While aiming down sights each press of the right trigger will burst fire, not aiming will give you rapid fire.

3 or 5 Round Burst for Auto's
This mode turns fully auto weapons into burst weapons.

LT Cancellation
Jumpshot and Dropshot both have LT cancellation, if you pull LT before RT, the command will be cancelled.

Auto Aim
With LT pressed the mod will automatically aim on to the nearest target to your gun crosshairs.
(Offline only, unless aim assist is built into the online game)

Jump Shot
Pressing (RT) will make your player jump while shooting, once you start to jump LT can be pressed to aim in.

MODE LIST

MAIN MODES	
1	RT Rapidfire
2	RT Rapidfire
3	Autorun Rapidfire
4	Auto ADS with Rapidfire
5	3 Shot Burst for Automatic Weapons
6	Jump, Drop, Autorun and Rapidfire
7	Quickscope
8	Quickscope Doubleshot
9	3 Round Burst with Rapidfire
10	3 Round Burst no Rapidfire
11	Dropshot with Rapidfire
12	Dropshot ADS with Rapidfire
13	Jumpshot with Rapidfire
14	Jumpshot ADS with Rapidfire
15	Jumpshot Dropshot with Rapidfire
16	Jumpshot Dropshot ADS with Rapidfire
17	Aim Kneel Reset with Rapidfire
18	Autoaim with Rapidfire

SUB MODES	
1a	Akimbo Mimic
2a	Akimbo Mimic
3a	Autorun no Rapidfire
4a	Auto ADS no Rapidfire
5a	5 Shot Burst for Automatic Weapons
6a	Jump, Drop, Autorun no Rapidfire
7a	Quickscope Sniperbreath
8a	Quickscope Doubleshot Sniperbreath
9a	5 Round Burst with Rapidfire
10a	5 Round Burst no Rapidfire
11a	Dropshot no Rapidfire
12a	Dropshot ADS no Rapidfire
13a	Jumpshot no Rapidfire
14a	Jumpshot ADS no Rapidfire
15a	Jumpshot Dropshot no Rapidfire
16a	Jumpshot Dropshot ADS no Rapidfire
17a	Aim Kneel Reset no Rapidfire
18a	Autoaim no Rapidfire

UP YOUR GAME
WITH X-MODS CONTROLLERS

PROGRAMMING

PROGRAMMING/CHANGING THE MODE SPEED IN S.P.S (shot per second)

- To enter programming press and hold RT and tap the sync button, then release the RT
- The player LED will now start to flash, each flash represents the speed in s.p.s. Quick flashes are decimals (0.1 sps)
- To change the speed you use the triggers.
- Each time the speed is changed the led will flash the new set s.p.s.
- To increase the speed by +1 s.p.s press RT.
- To decrease the speed by -1 s.p.s press LT.
- To increase by 0.1 s.p.s press SYNC, at 0.9 the next press it will go back to .0.
- To exit programming, hold RT and tap sync once.
- Rapidfire speeds go higher than any game will allow, if you go too high the gun will fire slower or not at all.

S.P.S SET TOO HIGH

If you find that a gun stutters while shooting or the burst modes shoot fewer bullets than they should, the s.p.s is set too high for the game/gun to recognise. To fix this simply lower the s.p.s until the correct bullets are fired or the gun stops stuttering.

PROGRAMMING THE QUICK SCOPE TIMING/DELAY BEFORE SHOOTING

- First make sure you are in the quick scope mode. (Mode 7)
- Enter the programming mode. (RT + SYNC)
- The player LED will now start to flash the speed in s.p.s, then flash faster for decimal (0.1s.p.s)
- To change the speed you use the triggers and the sync button
- Each time the speed is changed the led's will flash the new s.p.s.
- **RT +1s.p.s / LT -1s.p.s / SYNC +0.1s.p.s.**
- Exit programming tap SYNC.

NOTE IN QUICK SCOPE MODE THE LOWER THE S.P.S THE FASTER THE QUICK SCOPE

FASTEST quick scope speed 1 s.p.s
SLOWEST quick scope speed 6 s.p.s
For beginners start a 6 s.p.s then adjust accordingly.
In the quick scope mode taking your left thumb off the left analogue stick before pressing LT will increase the accuracy of the shot

If you have any problems what so ever, please don't hesitate to contact us. Our contact details are on the bottom of this page as you will see.

If you're happy with your controller and the service we have provided ***please remember to leave a 5 star rating and positive feedback,*** our business relies heavily on ratings so each one is greatly appreciated.

Are you a member of Facebook? We started a Facebook group a while back, were slowly building up a member base on there, why don't you head along and Like our page. All the latest updates, news and new products will also be listed on there. So if you'd like to support us and stay up to date, come and say hi, you can find us at www.facebook.com/xmodscontrollers

You can also find us on Instagram: X_MODS_LTD

Email: aftercare@x-mods.co.uk
Website: www.x-mods.co.uk
Phone: 07877743921
facebook.com/xmodscontrollers

SDOM
UP YOUR GAME
WITH X-MODS CONTROLLERS